# NLC TAMILNADU POWER LIMITED



## **DEPARTMENTAL PROCEDURE MANUAL**

(Incorporating ISO 9001:2015, ISO 14001: 2015 & ISO 45001: 2018)

### STANDARD OPERATING PROCEDURE

TITLE:- SOP FOR VACUUM DROP TEST PEOCEDURE	Doc. ID: NTPL/OPRN/SOP-32	
REVISION :02	DATE:25/10/2022	

**PURPOSE:** To define Procedure for Vacuum Drop Test

**SCOPE:** This SOP is applicable at NTPL

**RESPONSIBILITY:** Shift Engineer / Operation Engineer

#### **ACTIVITIES:**

#### Vacuum Test Procedure to be followed-

- Test to be performed with constant schedule and stable load for atleast 10 mins or Condenser Pr 0.1500 Ksc(a) whichever comes first.
- 2. Test to be performed at lower CW inlet temperature.
- 3. For checking air flow through vacuum pump, corresponding Rotameter should be healthy.
- 4. Keep Vacuum Pump SLC Off during the test.
- 5. Keep Supervisor at local to monitor Vacuum pump condition.
- 6. Close Air Inlet valve of running vacuum pump.
- 7. Before and after the test, note down following readings:
  - i) Unit Generation MW
  - ii) Condenser Pr (ksc)
  - iii) Condenser Vacuum (mmHg)
  - iv) Air Suction Temperature near condenser
  - v) CW Inlet Temperaure
  - vi) CEP Suction Temperature
  - vii) LP Exhaust Hood Temperature
  - viii) Vacuum Pump Suction Pressure
- 8. After completion of test, Open Air inlet temperature of Running Vacuum pump and SCL ON.
- 9. Record Drop in Vacuum as: (Bef Vacuum- Aft Vacuum) mmHg/Time duration

PREPARED BY	REVIWED BY	VERIFIED BY	APPROVED BY
S.GANAPATHY ACM/O&S	S.RADHAKRISHNAN NAIR DGM – O&S, Safety	S.GANAPATHI GM – O&M	K.KONDASKUMAR CEO